
# **Image Capture**

Yih-Lon Lin (林義隆)

**Associate Professor**,

Department of Computer Science and Information Engineering, National Yunlin University of Science and Technology

# **Digital Image Processing**



# Image Formation on Camera

How human eye works?







Image formation on analog cameras




#### Pinhole Camera Model




#### Pinhole Camera Model






#### Lens-Camera Model









https://en.wikipedia.org/wiki/Lens#Imaging\_properties

#### Pinhole Camera Model




https://allen108108.github.io/blog/2020/02/06/%E9%87%9D%E5%AD%94%E7%9B%B8%E6%A9%9F%E6%A8%A1%E5%9E%8B%20%20Pinhole%20Camera%20Model/






https://chtseng.wordpress.com/2018/09/18/%E5%A6%82%E4%BD%95%E4%BC%B0%E7%AE%97%E5%89 %8D%E6%96%B9%E4%BA%BA%E7%89%A9%E7%9A%84%E8%B7%9D%E9%9B%A2/

#### **How to Calculate FOV**






Compromise between many competing factors



How to calculate Focal Length of a lens

**F = Working Distance x CCD Height / Object Height** 



f = WD \* Opt. Mag(Sensor size(V or H) / FOV(V or H))


f = 2000mm \* Opt.Mag(= Sensor size(4.8mm) / FOV(200mm))

f = 48mm



#### Field of View

How to calculate Field of View (FOV)





FOV(V or H) = WD \* Sensor size(V or H) / f(focal length) FOV = 1500 \* 4.8 / 50 = 144mm

# **Computer Vision**



https://www.lightingseika.com.tw/product\_des cription.php?PNo=221







Working distance

Resolution


https://www.ni.com/zh-tw/support/documentation/supplemental/18/calculating-camera-sensor-resolution-and-lens-focal-length.html








https://capturetheatlas.com/what-is-focal-length/



LENS FOCAL LENGTH ANGLE OF VIEW COMPARISON

#### **FOCAL LENGTH**

#### & ANGLE OF VIEW GUIDE




capturetheatlas.com




**☆ ② @Capturetheatlas**






https://av.jpn.support.panasonic.com/support/global/cs/dsc/knowhow/knowhow12.html






https://av.jpn.support.panasonic.com/support/global/cs/dsc/knowhow/knowhow13.html



https://nerdyphotographer.com/tips-techniques/lens-focal-length-part-one/

### **Lens Optical Format**




https://www.dimagemaker.com/understanding-canon-ef-s-nikon-dx-and-similar-lenses-for-small-sensor-digital-slr-cameras/




國立雲林科技大學

### **Lens Optical Format**



https://www.1stvision.com/machine-vision-solutions/2017/08/how-does-a-lens-opticalformat-relate-to-machine-vision-cameras.html 國立雲林科技大學

# **Computer Vision**



#### Sensor Size

Sensor size is the size of the sensor inside a camera Pixel size is the size of image sensor that compose image sensor Sensor size = Pixel size (V) or (H) x Effective Pixel amount (V) or (H) ex:


Pixel size: 4.4µm x 4.4µm

Effective Pixel amount: 1600 x 1200

Sensor size (H) =  $0.0044 \times 1200 = 5.28 \text{mm}$ 

Sensor size (V) =  $0.0044 \times 1600 = 7.04$ mm


Sensor size =  $7.04 \times 5.28 \text{ mm}$ 





### **Lens Optical Format**

- Standard area-scan sensor sizes
  - ½", 1/3", ½", 1/1.8", 2/3", 1" and 1.2"



https://www.baslerweb.com/en/vision-campus/vision-systems-and-components/find-the-right-lens/

#### **Sensor Size**

#### CMOS Camera (acA2440-20gm - Basler ace)

- The Basler acA2440-20gm GigE camera with the Sony IMX264 CMOS sensor delivers 23 frames per second at 5.0 MP Resolution.
- Sensor Size: 8.4 mm x 7.1 mm
- Resolution (H x V): 2448 pixle x 2048 pixel
- Resolution: 5 million pixel camera
- Pixel Size (H x V): 3.45 μm x 3.45 μm Sensor Size:
  - $2448 \times 3.45 \mu m = 8.445 mm$
  - $2048 \times 3.45 \, \mu m = 7.065 \, mm$

#### • Lens (ICL-DM2518I-5M)

-25mm 0.083x -0.05x 300 - 500 1.8






https://www.baslerweb.com/en/products/cameras/area-scan-cameras/ace/aca2440-20gm/https://www.photon-tech.com.tw/zh/product/show/54



#### **Q** & **A**



#### **Sensor Size**

#### CMOS Camera (BTK-CA060-11GM)

- Sensor Size: 7.37 mm x 7.37 mm
- Resolution (H x V): 3,072 pixel  $\times$  2,048 pixel
- Resolution: 6 million pixel camera
- Pixel Size (H x V): 2.4μm×2.4μm



- 12mm 2/3吋 5M Len







#### Reference

#### Learn DIP

https://www.tutorialspoint.com/dip/index.htm

#### Stanford

- https://web.stanford.edu/class/cs231a/course\_notes/
- https://www.scratchapixel.com/lessons/3d-basic-rendering/3dviewing-pinhole-camera
- https://www.itreado1.com/content/1543965183.html
- https://www.sipotek.com/hyxw/314.html
- https://allen108108.github.io/blog/2020/02/06/%E9%87%9D%E5 %AD%94%E7%9B%B8%E6%A9%9F%E6%A8%A1%E5%9E%8B%2 0%20Pinhole%20Camera%20Model/

#### Resolution

攝影機	解析度	掃瞄線(TV LINE)	圖素(PIXELS)	明亮環境	昏暗環境
CCD 彩色攝影機	高解析	470條~580條	38萬~41萬	畫質較細膩	較差
	中解析	330條~420條	25萬~29萬	佳	佳
CCD 黑白攝影機	高解析	480條~600條	38萬~41萬	畫質較細膩	較差
	中解析	350條~420條	25萬~29萬	佳	佳
CMOS (黑白彩色) 攝影機	高解析	350條	35萬	不佳	不佳
	中解析	330條	25萬	不佳	不佳
	低解析	250條	10萬	不佳	不佳

https://documen.site/download/5af6of28f053c\_pdf#

#### C270 Camera

• Logitech C270 camera is not focused at the scanner working distance (about 300 mm), but it is focused at a longer distance. This may cause inaccurate pattern detection and worse calibration values.

